

## Centrifugation

### Types of different centrifuges and their uses

- Centrifugation is a technique of separating substances which involves the application of centrifugal force.
- The particles are separated from a solution according to their size, shape, density, the viscosity of the medium and rotor speed.

### INTRODUCTION

- **Centrifugation** is a process which involves the use of the centrifugal force for the sedimentation of heterogeneous mixtures with a centrifuge, used in industry and in laboratory settings.
- This process is used to separate two immiscible liquids.
- More-dense components of the mixture migrate away from the axis of the centrifuge, while less-dense components of the mixture migrate towards the axis.


- **Centrifugation** is a process which involves the use of the centrifugal force for the sedimentation of heterogeneous mixtures with a centrifuge, used in industry and in laboratory settings.
- This process is used to separate two immiscible liquids.
- More-dense components of the mixture migrate away from the axis of the centrifuge, while less-dense components of the mixture migrate towards the axis.

# Principle of Centrifugation

### PRINCIPLE


- A centrifuge is a device for separating particles from a solution according to their size, shape, density, viscosity of the medium and rotor speed.
- In a solution, particles whose density is higher than that of the solvent **sink (sediment)**, and particles that are lighter than it **float to the top**.
- The greater the difference in density, the faster they move. If there is no difference in density (isopycnic conditions), the particles stay steady.

- To take advantage of even tiny differences in density to separate various particles in a solution, gravity can be replaced with the much more powerful "**centrifugal force**" provided by a centrifuge.



- In a solution, particles whose density is higher than that of the solvent sink (sediment), and particles that are lighter than it floats to the top.
- The greater the difference in density, the faster they move. If there is no difference in density (isopycnic conditions), the particles stay steady.
- To take advantage of even tiny differences in density to separate various particles in a solution, gravity can be replaced with the much more powerful "centrifugal force" provided by a centrifuge.
- A centrifuge is a piece of equipment that puts an object in rotation around a fixed axis (spins it in a circle), applying a potentially strong force perpendicular to the axis of spin (outward).

- The centrifuge works using the sedimentation principle, where the centripetal acceleration causes denser substances and particles to move outward in the radial direction.
- At the same time, objects that are less dense are displaced and move to the center.
- In a laboratory centrifuge that uses sample tubes, the radial acceleration causes denser particles to settle to the bottom of the tube, while low- density substances rise to the top.




# Types of Centrifuge

## CENTRIFUGE

- A **centrifuge** is a piece of equipment that puts an object in rotation around a fixed axis (spins it in a circle), applying a potentially strong force perpendicular to the axis of spin (outward).
- The centrifuge works using the sedimentation principle, where the centripetal acceleration causes denser substances and particles to move outward in the radial direction.
- At the same time, objects that are less dense are displaced and move to the center. In a laboratory centrifuge that uses sample tubes, the radial acceleration causes denser particles to settle to the bottom of the tube, while low-density substances rise to the top.

## INSTRUMENTATION

- It consists of two components, an electric motor to spin the sample and a rotor to hold tubes.



## 1. LOW-SPEED CENTRIFUGE

- 1) Most laboratories have a standard low-speed centrifuge used for routine sedimentation of heavy particles
- 2) The low-speed centrifuge has a maximum speed of 4000-5000rpm
- 3) These instruments usually operate at room temperatures with no means of temperature control.
- 4) Two types of rotors are used in it,
  - Fixed angle
  - Swinging bucket.
- 5) It is used for sedimentation of red blood cells until the particles are tightly packed into a pellet and supernatant is separated by decantation.

## HIGH-SPEED CENTRIFUGES

1. High-speed centrifuges are used in more sophisticated biochemical applications, higher speeds and temperature control of the rotor chamber are essential.
2. The high-speed centrifuge has a maximum speed of 15,000 – 20,000 RPM
3. The operator of this instrument can carefully control speed and temperature which is required for sensitive biological samples.

4. Three types of rotors are available for high-speed centrifugation-
  - Fixed angle
  - Swinging bucket
  - Vertical rotors

## ULTRACENTRIFUGES

1. It is the most sophisticated instrument.
2. Ultracentrifuge has a maximum speed of 65,000 RPM (100,000's x g).
3. Intense heat is generated due to high speed thus the spinning chambers must be refrigerated and kept at a high vacuum.
4. It is used for both preparative work and analytical work.

## Types of Centrifugation

1. **Differential Pelleting (differential centrifugation)**
  - It is the most common type of centrifugation employed.
  - Tissue such as the liver is homogenized at 32 degrees in a sucrose solution that contains buffer.
  - The homogenate is then placed in a centrifuge and spun at constant centrifugal force at a constant temperature.
  - After some time a sediment forms at the bottom of a centrifuge called pellet and an overlying solution called supernatant.
  - The overlying solution is then placed in another centrifuge tube which is then rotated at higher speeds in progressing steps.
2. **Density Gradient Centrifugation**
  - This type of centrifugation is mainly used to purify viruses, ribosomes, membranes, etc.
  - A sucrose density gradient is created by gently overlaying lower concentrations of sucrose on higher concentrations in centrifuge tubes
  - The particles of interest are placed on top of the gradient and centrifuge in ultracentrifuges.

- The particles travel through the gradient until they reach a point at which their density matches the density of surrounding sucrose.
  - The fraction is removed and analyzed.
3. **Rate-Zonal Density-Gradient Centrifugation**
- Zonal centrifugation is also known as band or gradient centrifugation
  - It relies on the concept of sedimentation coefficient (i.e. movement of sediment through the liquid medium)
  - In this technique, a density gradient is created in a test tube with sucrose and high density at the bottom.
  - The sample of protein is placed on the top of the gradient and then centrifuged.
  - With centrifugation, faster-sedimenting particles in sample move ahead of slower ones i.e. sample separated as zones in the gradient.
  - The protein sediment according to their sedimentation coefficient and the fractions are collected by creating a hole at the bottom of the tube.
4. **Isopycnic Centrifugation**
- The sample is loaded into the tube with the gradient-forming solution (on top of or below pre-formed gradient, or mixed in with self-forming gradient)
  - The solution of the biological sample and cesium salt is uniformly distributed in a centrifuge tube and rotated in an ultracentrifuge.
  - Under the influence of centrifugal force, the cesium salts redistribute to form a density gradient from top to bottom.
  - Particles move to point where their buoyant density equals that part of gradient and form bands. This is to say the sample molecules move to the region where their density equals the density of gradient.
  - It is a "true" equilibrium procedure since depends on bouyant densities, not velocities

Eg: CsCl, NaI gradients for macromolecules and nucleotides – "self-forming" gradients under centrifugal force.

## Applications of Centrifugation

- To separate two miscible substances
- To analyze the hydrodynamic properties of macromolecules
- Purification of mammalian cells
- Fractionation of subcellular organelles (including membranes/membrane fractions) Fractionation of membrane vesicles
- Separating chalk powder from water
- Removing fat from milk to produce skimmed milk
- Separating particles from an air-flow using cyclonic separation
- The clarification and stabilization of wine
- Separation of urine components and blood components in forensic and research laboratories
- Aids in the separation of proteins using purification techniques such as salting out, e.g. ammonium sulfate precipitation.

#### OTHER APPLICATIONS

- Separating chalk powder from water
- Removing fat from milk to produce skimmed milk
- Separating textiles
- Removing water from lettuce after washing it in a salad spinner
- Separating particles from an air-flow using cyclonic separation

- The clarification and stabilization of wine
- Separation of water particles from clothes while spin-drying in washing machines
- Separation of urine components and blood components in forensic and research laboratory




## Types of Centrifuge Rotors

#### CENTRIFUGE ROTOR

- A centrifuge rotor is the rotating unit of the centrifuge, which has fixed holes drilled at an angle. Test tubes are placed inside these holes and the rotor spins to aid in the separation of the materials.



#### TYPES OF ROTOR



## SWING-BUCKET ROTOR

- A swing-bucket rotor usually supports samples ranging in volume from 36 mL to 2.2 mL. Swing-buckets can support two types of separations: rate-zonal and Isopycnic.
- Swing-buckets are preferred for rate-zonal separations, because the distance between the outside of the meniscus and the outside of the bottom of the tube is long enough for separation to occur.

## VERTICAL ROTOR

- Vertical rotors are highly specialized. They are typically used to band DNA in cesium chloride. Vertical rotors have very low K factors, which is useful if the particle must only move a short distance until it pellets. Run time on vertical rotors is short.

## FIXED-ANGLE ROTOR

- Fixed-angle rotors are usually used for pelleting applications to either pellet particles from a suspension and remove the excess debris, or to collect the pellet. Rotor cavities range from 0.2 mL to 1 mL.
- The most important aspect in deciding to use a fixed-angle rotor is the K factor. The K factor indicates how efficient the rotor can pellet at maximum speed. The lower the K factor, the higher the pelleting efficiency.